




























TV Box

EN Installation manual / **DE** Montageanleitung / **ES** Manual de montaje / **FR** Notice de montage /
IT Istruzioni di montaggio / **PL** Instrukcja montażu /
RU инструкция по монтажу


A1  x 1	B1  x 1	C1  x 1	D1  x 1	E1  x 1			
H1  x 2	I1  x 2	J1  x 1	K1  x 5	L1  x 4	M1  x 4	N1  x 6	O1  3x20 x 23
P1  x 2	R1  x 16	S1  x 8	T1  5x45 x 4	U1  x 16	W1  3,5x16 x 8	Y1  3x20 x 6	Z1  x 1
F1.1  x 1	G1.1  x 1	H1.1  x 2					




1.




2.




3.




4.




5.




6.




7.




8.




9.




10.




11.



12.



13.



14.

